

## NOMAD Power Distribution Systems

ORDER  
CODE

NOMAD 63



OUTLETS	QUANTITY	VOLTAGE	CONFIGURATION
63A*	1	400V	3PH + E +N
32A*	2	400V	3PH + E +N
32A	2	400V	3PH + E +N
16A	2	230V	2P + E
15A	2	230V	2P + E
10A	10	230V	2P + E

\* Interconnection Outlets

NOMAD 32



NOMAD 32

OUTLETS	QUANTITY	VOLTAGE	CONFIGURATION
32A*	1	400V	3PH + E +N
32A	1	400V	3PH + E +N
16A	1	230V	2P + E
15A	2	230V	2P + E
10A	6	230V	2P + E

\* Interconnection Outlets


NOMAD S32



NOMAD S32

OUTLETS	QUANTITY	VOLTAGE	CONFIGURATION
16A	1	230V	2P + E
10A	6	230V	2P + E

NOMAD R10



NOMAD R10

OUTLETS	QUANTITY	VOLTAGE	CONFIGURATION
10A	6	230V	2P + E