

WILLIS FLOODLIGHT

WILLIS10/WILLIS30/WILLIS50
WILLIS100/WILLIS150/WILLIS200

SAFETY INFORMATION

- This product should be installed by a suitably qualified person in accordance with Australian and New Zealand wiring rules. In the case of lamp failure, disconnect from the main supply and return to Vynco for service.
- Do not make or alter any holes in the luminaire.
- Do not modify the luminaire.
- Do not install if the luminaire or supply cable is damaged.
- Isolate from the power supply before installation or servicing.
- Do not put any installation around or over light.
- Caution light casing may be hot.
- Allow luminaire to cool before touching and handling.
- Suitable for indoor and outdoor applications.

INSTALLATION INSTRUCTIONS

- Ensure desired location is suitable and clear from all obstructions.
- Mount the flood light securely into desired location.
- Adjust light angle by loosening hand knobs and moving the light body until orientation of light suits application.
- Tighten hand knobs to secure light angle.
- Terminate wiring.
- Test to ensure correct operation.

WIRING

L = LIVE OR PHASE - BROWN OR RED
E = EARTH - GREEN OR YELLOW
N = NEUTRAL - BLUE OR BLACK

WARRANTY

This product is covered by the standard 3 year Vynco Warranty - proof of purchase is required. Please contact Vynco for details of returns procedure.

VYNCO INDUSTRIES (NZ) LIMITED

Christchurch Office
388 Tuam Street, Phillipstown, Christchurch, 8011
PO Box 9022, Tower Junction, Christchurch 8149
New Zealand
P +64 3 379 9283 F +64 3 379 6838
E sales@vynco.co.nz

VYNCO.CO.NZ

Auckland Office
9 Levene Place, Mount Wellington
PO Box 12 249, Penrose, Auckland 1061
New Zealand
P +64 9 525 6051 F +64 9 525 5799
E sales@vynco.co.nz