

VYNCO LIGHTING


INSTALLATION INSTRUCTIONS AND SPECIFICATIONS Stallone 'F' Range of LED Floodlights

Drill 2 holes in the cement wall/ground with electric drill.




3 Lock mounting bracket into the cement wall/ ground with plain washer, spring washer and nut.







2 Tap the screws into the holes as the sketch shows.



4 Connect the power wire and make insulation and water-proof processing. Please look at detail A at the wiring place.

Please connect wires as per appropriate color of power cords as shown in diagram.





Loosen screws of lamp arm with spanner to adjust lamp body until the beam angle meet with customer's requirement, then lock the screws with spanner.



Luminaire can not be directly installed on the surface of ordinary flammable material in any circumstance.

Warning: If outer flexible cable or cord of luminaire are damaged, only the manufacturer, its agent or other eligible people can replace them to avoid accident.

VYNCO LIGHTING

INSTALLATION INSTRUCTIONS AND SPECIFICATIONS Stallone 'F' Range of LED Floodlights

WARNING

Product is strictly prohibited to be installed in the airtight space.

Products cannot be directly contacted with the ground; it is strictly prohibited to be used as platform or other purposes.

If Product is damaged in the transportation process, it is strictly prohibited to use.

NOTES

Please use professional electricians to install the fitting

If any abnormal situation occurs during install, please cut off the power supply.

Please clean the floodlight glass part regularly; to keep great lighting transmission effect.

Please remove the dust of floodlight shell termly, in order to keep good heat dissipation effect.

Please do a good anti-thunder work in power supply input end, so it can keep stable working voltage.

Don't clean with water or caustic solution, please use the dry dishcloth.

The fitting must be grounded.

There is high voltage inside the fitting, please don't remove it to prevent electric shock.

As there is glass accessory, please handle it gently during handling and storage.

The external flexible cable and cord cannot be replaced. If there is any damage, the fitting should be discarded.



CORRECT DISPOSAL OF THIS PRODUCT

This marking indicates that this product should not be disposed with other household waste. To prevent possible harm to the environment or

human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

WARRANTY:

4 Year Warranty - proof of purchase is required. Warranty is void if the manufacturer instructions are not followed correctly.